

## SECTION 4

# FUEL SYSTEM

### NOTICE:

For the items not found in this section, refer to the Section "4. FUEL SYSTEM" of 99500-84000-01E SERVICE MANUAL (ALTO).

### FUEL PUMP, FILTER AND LINES

#### General




Fig. 4-1

